

PB-227 857

XYPLOT

Paul R. Dorn

Federal Water Pollution Control Administration
Annapolis, Maryland

July 1969

DISTRIBUTED BY:

NTIS

National Technical Information Service
U. S. DEPARTMENT OF COMMERCE
5285 Port Royal Road, Springfield Va. 22151

Chesapeake Technical Support Laboratory
Middle Atlantic Region
Federal Water Pollution Control Administration
U.S. Department of the Interior

Technical Report No. 23

Reproduced from
best available copy.

XYPLOT ✓

by

Paul R. Dorn

July 1969

Johan A. Aalto, Chief, CTSL
Norbert A. Jaworski, Chief, Engineering Section
Richard Burkett, Draftsman

XYPLOT was written to aid the Chesapeake Technical Support Laboratory of the Middle Atlantic Region, Federal Water Pollution Control Administration in analyzing and displaying data.

This program uses a modified version of the subroutine PLOT written by the computing center of the Johns Hopkins University. This modified subroutine was incorporated in the plotting package, LNEPLT. For further information on this package, see Technical Report No. 21.

XYPLOT is operational on the IBM 360/Model 65 at the United States Geological Survey, Department of the Interior in Washington, D.C. The program was compiled using the IBM G-level compiler. The program should work with little or no change on any 360 IBM computer having a G or H level compiler.

For further information regarding this and other current plotting routines, contact Dr. Norbert Jaworski, CTSL, Annapolis Science Center, Annapolis, Maryland, 21401, or phone 1-301-268-5038.

TABLE OF CONTENTS

	<u>Page</u>
PURPOSE	1
DESCRIPTION	2
RESTRICTIONS	3
PROGRAM RUN PREPERATION	4
JOB CARD	5
SYSTEM CONTROL CARDS	8
HEADER CARD	10
OPTIONS	11
VARIABLE SELECTOR CARD	12
OBSERVATION SELECTOR CARD	13
VARIABLE ID CARD	14
LINE COUNT CARD	15
RANGE CARD	16
END CARD	17
DRAWINGS	18
APPENDIX: FLOWCHART AND SOURCE LISTING	23
APPENDIX: USE OF XYPLOT WITH CARD ENTRY PROGRAM	34
APPENDIX: SAMPLE PROBLEM	37

PROGRAM: XYPLOT

PURPOSE: XYPLOT is a STATPAC format program which produces a line plot of one or two dependent variables versus a common independent variable.

DESCRIPTION:

XYPLOT will plot on the 1403 printer one or two dependent variables versus a common independent variable for any number of observations. Each plot can contain from 1 to 400 points for each Y (dependent) variable. If more observations are selected, they are plotted on another graph. The scales are varied from graph to graph, even within the same job (e.g. if 600 points are to be plotted, the scale for the first plot--which might contain 400 points, is different from the scale for the second graph--which contains the other 200 points.) This feature may be overridden by selecting your own scaling factors. (See the RANGE SELECTOR CARD.)

Options are available to vary the number of lines in the Y-direction (50 lines is the default option), to specify the number of points per plot (default selection is 200), to use a common Y as well as a common X scale, to select your own scales for the axes, to rename the selected variables, and to select specific observations.

The program will handle indeterminant values as well as complete observations. The program checks the indeterminant codes of the three (or two) selected variables. If all of them are blank, the observation is used. If the X-variable is indeterminant, the observation is skipped.

Normally, the observation is also skipped if either of the Y-variables has an indeterminant code. However, an option is available so if only one of the Y-variables does not contain an indeterminant, that point will be plotted and the other Y-value ignored. (Naturally

this option is not used when plotting a single Y-variable.) Therefore, the number of points of the first Y-variable plotted does not have to equal the number of points of the second Y-variable plotted. The plot is generated as soon as one of the Y-variables has the maximum number of points per plot, regardless of the status of the other Y-variable. (See the NUMBER OF POINTS/PLOT CARD.)

RESTRICTIONS:

A maximum of 99999 rows (observations) and 199 columns (variables) is permitted on the input tape, with a maximum of 199 pairs of selected rows with a total of 99999 individual rows, and two or three selected columns.

PROGRAM RUN PREPERATION:

The following is a complete deck setup for this program:

1. JOB card
2. System control cards (including object or source deck)
3. Header card
4. Variable selector card
5. Observation selector card*
6. Variable ID card*
7. Line count card*
8. Number of points/plot card*
9. Range card*
10. End card (delimiter)

*Optional cards--see the various sections for the usage of each card.

If more than one run is to be performed, repeat cards three through nine as necessary. The final card should be the delimiter card.

JOB CARD:

The JOB card cannot be catalogued and its installation as well as machine dependent. Below is the specification for the 360/65 located in the Department of the Interior building, in Washington D.C. The structure of the JOB card changes occasionally, and one should check with the computer center before using the below form.

Card 1 -

Card ColumnsContents

1 - 2	//
3	Center Code: D = Denver, Colorado F = Flagstaff, Arizona I = Crystal Plaza, Virginia M = Menlo Park, California R = Rolla, Missouri W = Washington, D.C.
4 - 5	Agency Code.
6 - 8	User registration code.
9 - 10	User's ID. May be changed by user as desired. Do not use the same two characters for different jobs run during the same day.
11	Blank.
12 - 14	JOB (i.e. the word JOB).
15	Blank.
16	((Left parenthesis).
17 - 20	Program Number.

<u>Card Columns</u>	<u>Contents</u>
21	, (Comma).
22 - 25	Auxiliary account number.
26	, (Comma).
27 - 30	Estimated execution time in minutes. Requires four numeric digits.
31	, (Comma).
32 - 35	Estimated lines of print expressed in thousands of lines. Requires four digits.
36	, (Comma).
37 - 40	Estimated number of cards to be punched. Requires four numeric digits.
41	, (Comma).
42	Reserved for future use; must be a 1 punch.
43	, (Comma).
44	Reserved for future use; must be a 1 punch.
45	, (Comma).
46	Type of run: C = Compile only T = Test of program P = Production use of program
47	, (Comma).
48 - 49	Number of lines per page. A value of zero suppresses page overflow tests. If this field (and the preceding comma) is elimin- ated, a default option of 61 lines per page is used. In this case the following fields are shifted left 3 columns. (Except 62-72)
50	) (Right parenthesis).
51	, (Comma).

Card ColumnsContents

52	' (Apostrophe).
53 - 61	Name of the user.
62	' (Apostrophe).
63	, (Comma).
64 - 71	Blank.
72	X (The letter X).

Card 2 -

Card ColumnsContents

1 - 2	//
3 - 15	Blank.
16 - 25	MSGLEVEL=1
26	, (Comma).
27 - 33	CLASS=C
34 - 72	Blank.

SYSTEM CONTROL CARDS:

If an object deck is used:

Card 1 -

```
1
//bEXECbLINKFORT,REGION.GO=100K,TIME.GO=J
```

where J is the time required to run the program (in minutes).
The b stands for a blank space.

Card 2 -

```
1
//LKED.SYSINbDDb*
```

Next comes the object deck (including its delimiter).

If a source deck is used:

Card 1 -

```
1
//bEXECbFORTGCLG,PARM.FORT='DECK',REGION.GO=100K,TIME.GO=J
```

where J is as before.

Card 2 -

```
1
//FORT.SYSINbDDb*
```

Next comes the source deck (including its delimiter).

Cards 3 & 4 -

If the data resides on the disc SYSDK:

```
1
//GO.FT1OFCO1bDDbDSN=&NAME,UNIT=SYSDK,DISP=(OLD,PASS,DELETE),
//bDCB=(RECFM=VB,LRECL=RRR,BLKSIZE=BBBB)
```

where &NAME is the name of the storage space. (The & signifies the storage is temporary--it exists only for the extent of the job.)

PASS is used if the data file is used later on; otherwise use DELETE.

If the data resides on magnetic tape, use the following cards:

```
1
//GO.FT1OFOO1bDDbUNIT=2400,LABEL=(,SL),VOLUME=(,RETAIN,,,SER=YYYYY),
//bDCB=(RECFM=VB,LRECL=RRR,BLKSIZE=BBBB),
//bDISP=(OLD,KEEP),DSN=STAPAC
```

The letters "YYYYYY" in the first tape card represent a six digit input tape number (leading zeros must be given).

The quantities "RRR" and "BBBB" are computed as follows:

$RRR = 8M + 24$ where M = number of columns in the data matrix.

$BBBB = K(RRR) + 4$ where K is an integer chosen so that the positive difference $(7200 - BBBB)$ is as small as possible.

If a tape is used, a tape setup card is required. Its form is:

<u>Columns</u>	<u>Contents</u>
1 - 9	/*MESSAGE
10 - 12	Blank.
13 - 20	The same characters as in columns 3-10 of the JOB card.
21 - 22	Blank.
23 - 27	SETUP
28 - 29	Blank.
30 - 36	The number of the tape used (i.e. YYYYYY).
37 - 38	/9

If the tape is written on as well as read during this job, in column 39 place an R (for ring in). This card should be placed right after the JOB card. (This card's format is particular to the 360/65 in Washington D.C.)

Card 5 -

```
1
//GO.SYSINbDDb*
```

HEADER CARD -

<u>Columns</u>	<u>Format</u>	<u>Entry</u>	<u>Description</u>
1-30	7A4,A1	TITLE	Up to 30 characters of alpha-numeric information used to title the output for this data set. It is also used as the title of the graph.
31-38	2A4	INPUT ID	Up to 8 characters of alpha-numeric information used to identify the input data set.
39-43	I5	INPUT N	The number of rows in the input data matrix (right justified).
44-46	I3	INPUT M	The number of columns in the input data matrix (right justified, 199).
47-56	10I1	OPTIONS	See the following sheet.
73-77	I5	PRON	The number of pairs or row numbers needed to select the desired rows of the input matrix. (If blank, all rows are included. If not blank, this number must be right justified and row selector cards must be included.)

OPTIONS -

- 0 - 50 lines are used for the Y-axis.
OPTION(1) - 1 - LINE COUNT card gives the number of lines in the Y-direction.
- 0 - 200 points for each Y-variable are plotted per graph.
OPTION(2) - 1 - POINTS/PLOT card gives the number of points for each variable to be plotted per graph.
- 0 - Both Y-variables must not contain indeterminants for the points to be plotted.
OPTION(3) - 1 - If one of the Y-variables does not contain an indeterminant, that point will be plotted.
- 0 - Two Y-variables will be plotted.
OPTION(4) - 1 - One Y-variable will be plotted.
- 0 - Separate Y-scales are calculated.
OPTION(5) - 1 - A common Y-scale is used.
- 0 - The program calculates the minimum and maximum values of the plot's scale.
OPTION(6) - 1 - The user supplies maximum and minimum values to be used in scaling.
- OPTION(7) - NOT USED.
- OPTION(8) - NOT USED.
- OPTION(9) - NOT USED.
- 0 - No action taken.
OPTION(10) - 1 - New variable names are read in for the three (or two) selected variables.

VARIABLE SELECTOR CARD -

In columns 1-3 place the number of the independent variable. The first Y variable should be placed in columns 4-6. The second dependent variable should be placed in columns 7-9. (If only one Y variable is to be plotted, leave columns 7-9 blank.) The numbers should be right justified.

OBSERVATION SELECTOR CARD -

These cards are used only if PRON on the HEADER card is non-zero. The number of pairs of row numbers used to select the desired rows of the data matrix is entered in the field PRON, right justified. Each pair specifies that the rows FROM and including the first member of the pair TO and including the last member of the pair to be selected. The pairs must be entered starting in the left most field of the card (columns 1-5) and continuing across eight pairs per card. If more pairs are used, continue on another card. If a particular pair consists of only one observation, the FROM portion should be completed and the TO portion left blank. The 'FROM' members are entered in columns 1-5, 11-15, 21-25, etc., while the 'TO' portions are entered in columns 6-10, 16-20, 26-30, etc.

The row numbers must form an increasing sequence (except the blank 'TO' field signifying a single observation); i.e. rows must be selected in the order they appear in the data matrix. These numbers must also be right justified.

VARIABLE ID CARD -

This card is used if OPTION(10) is not blank. In columns 1-8 place the new name of the independent variable. In columns 9-16 place the new name of the first dependent variable and in columns 17-24 place the name of the second dependent variable. Note that these names do not replace the original names on the STATPAC tape.

LINE COUNT CARD -

This card is used if OPTION(1) is not blank or zero. In columns 1-3, place the number of lines to be used for the Y-axis. This number should be right justified. Note that this is actually one less than the number of lines actually plotted since a zero line is used. This number should be a multiple of ten (10). Leaving this option blank gives a plot which just fills one page of output (50 lines). When using this option, be sure to specify page overflow test suppression on the JOB card if more than fifty lines/plot is desired.

RANGE CARD -

This card is used if OPTION(6) is non-zero. It gives the coordinates of the maximum and minimum values of the plot for the X and Y axes. If this option is not used, the maximum and minimum values of the variables being plotted gives the graph's range.

The format of the card is:

<u>Columns</u>	<u>Value</u>
1 - 10	XMIN
11 - 20	XMAX
21 - 30	YMIN1
31 - 40	YMAX1
41 - 50	YMIN2
51 - 60	YMAX2

The data may be entered in decimal or scientific notation. If only one Y-variable is plotted, columns 41-60 may be left blank. If a common Y-scale is desired, the Y-minima and Y-maxima should be the same. These values must be at least as large as the actual coordinates of the plotted values or else the normal method is used to select the ranges.

END CARD (delimiter) -

This must physically be the last card of the deck. It has the form:

1
/*

(Note that another delimiter occurs right after the object or source deck.)

JOB		
BY		DATE

PUNCHING INSTRUCTIONS

[illegible]

NOTES:

FIELD IDENTIFICATION

[illegible]

NAME

MSFLEVEL=1, CLASS=C

3/#MESSAGE V18000AA SETUP 004444/9R

011 EXEC. LINKFRT, REGION. GP: 100K, TIME. 60:2

3//LKED. SYSIN DD; 4

OBJECT DECK

1/1*

0011 EXEC FORTECLG, REGION.GM=100K, TIME.CD=2

00//FORT.SYSIN DD *

SOURCE DECK

11/2

12//69. FTIOFOOI DD UNIT=2400, LABEL=(,SL), VOLUME=(, RETAIN,, SER=004444), TAPE 7

```

// DCB=(RECFM=VB, LRECL=104, BLKSIZE=7180),
// DISP=(OLD YES)
// DCB=(RECFM=CB, LRECL=1, BLKSIZE=1), SER=004444, TAPE 7
// DISP=(OLD YES)
// DCB=(RECFM=CB, LRECL=1, BLKSIZE=1), SER=004444, TAPE 8

```

4// DISP.(OLD,KEEP),DSM-STAPAC TAPE 8
5//66 FINECC TO DSM-C TAPE 9

5//66 FTIOF001 DD DSN=ENAME,UNIT=SYSDK,DISP=(OLD,PASS,DELETE), TAPE 9
// DCR: (DECEM NO 12) DISC 7

NO.	OPERATION	DISC
1	11 DCB: (RECFM=VB, LRECL=104, BLKSIZE=7180)	DISC 7
2	11 DCB: (RECFM=VB, LRECL=104, BLKSIZE=7180)	DISC 8

PROGRAM CARDS

*/

20

IBM GENERAL PURPOSE CARD PUNCHING FORM

JOB	
BY	DATE

NOTES:

PUNCHING INSTRUCTIONS

[illegible]

FIELD IDENTIFICATION

[illegible]

LINE COUNT CARD


L	
2	3

POINTS/PLOT CARD


M	
---	--

RANGE CARD

INDEX	XMAX	Y1MIN	Y1MAX	Y2MIN	Y2MAX




DECK SETUP




PROGRAM SETUP

APPENDIX: Flowchart and Source Listing

24



FLOWCHART	01	OF	02
PROGRAM XYPLOT			



FLOWCHART	02	OF	02
PROGRAM XYPLOT			

X - Y LINE PLOTTER

```

C
C
      MAIN PROGRAM FOR X-Y PLOT
      INTEGER FOUT, POUT, STAPAC, TVID(199,2), CIO(2), CN, CM, TIO(2), TN, TM, TP
      $ LK, OPTION(10), TITLE(9), TIT(20)/4H GRA, 4HDMIC, 4HVAL A, 4HVALY, 4HSTS,
      $ 4H... 1444H /, ORSID(2), XNAME(2), YNAME(2), Y2NAME(2), SLO(199,2)
      $ J, TOTAL1, TOTAL2, A(200), RLK/4H /, LINE, PRON, MOUNT
      REAL X1PLOT(400), X2PLOT(400), Y1PLOT(400), Y2PLOT(400), X(199)
      INTEGER*2 SYMPL(3)
      EQUIVALENCE(TITLE(1), TIT(7))
      COMMON/LINEPL/Y1NAME, Y2NAME, LINE, XMIN, X(6), IOPY1, SYMPL
      FOUT = 5
      POUT = 6
      STAPAC = 10
      A(200) = RLK
      READ(PDIN, 900, END=170) TITLE, CIO, CN, CM, OPTION, PRON
      10  FORMAT(1A,15)
      900  FORMAT(7A4, A2, 2A4, I5, I3, I011, 15X, I5)
      READ(POUT, 910) IX, IY1, IY2
      910  FORMAT(3I3)
      IF(OPTION(4), NE.0) IY2=200
      IF(PRON, NE.0) GO TO 20
      PRON = 1
      SLO(1,1) = 1
      SLO(1,2) = CM
      GO TO 40
      20  READ(PDIN, 920) ((SLO(I,J), J=1,2), I=1, PRON)
      30  GO TO 1
      30  I = 1, PRON
      IF(SLO(1,2), EQ.0) SLO(1,2)=SLO(1,1)
      IF(OPTION(10), NE.0) READ(PDIN, 930) XNAME, Y1NAME, Y2NAME
      40  IF(OPTION(11), NE.0) READ(PDIN, 910) LINE
      MOUNT = 200
      IF(OPTION(2), NE.0) READ(PDIN, 910) MOUNT
      MOUNT = MAX(MOUNT, 10)
      MOUNT = MIN(MOUNT, 400)
      IF(OPTION(4), NE.0) READ(PDIN, 930) XMIN, X
      READ(STAPAC, END=180) TIO, TN, TM, ((TVID(1,J), J=1,2), I=1, TM)
      50  IF(TVID(1), EQ. CIO(1)) AND. (TVID(2), EQ. CIO(2)) GO TO 70
      GO TO 1
      180  I = 1, TN

```

XVP 0
 XVP 10
 XVP 20
 XVP 30
 XVP 40
 XVP 50
 XVP 60
 XVP 70
 XVP 80
 XVP 90
 XVP 100
 XVP 110
 XVP 120
 XVP 130
 XVP 140
 XVP 150
 XVP 160
 XVP 170
 XVP 180
 XVP 190
 XVP 200
 XVP 210
 XVP 220
 XVP 230
 XVP 240
 XVP 250
 XVP 260
 XVP 270
 XVP 280
 XVP 290
 XVP 300
 XVP 310
 XVP 320
 XVP 330
 XVP 340
 XVP 350
 XVP 360
 XVP 370
 XVP 380
 XVP 390

```

90 READISTAPAC,END = 100)
91 GO TO 50
92 WRITE (PRINT,1000) TITLE,CID,CN,CW,OPTICN
1000 FORMAT (1X,Y PLACING//7X, TITLE,22X,10OUT 10,7X,10,5X,10,4
1X,1000 OPTICN,10,1X,74X,12,3X,24X,3X,15,3X,13,3X,1012//)
1010 IF (CN.EQ.0) GO TO 60
1020 WRITE (PRINT,1010) TN,CN,CID
1030 GO TO 10
1040 IF (TN.EQ.0) GO TO 60
1050 WRITE (PRINT,1020) TN,CN,CID
1060 GO TO 10
1070 FORMAT (1X,TYPE,M,16,1 NOT EQUAL CARD M,16,1 FOR DATA SET 1,264)
1080 FORMAT (1X,TYPE,M,14,1 NOT EQUAL CARD M,14,1 FOR DATA SET 1,264)
1090 IF (OPTION(1).NE.0) GO TO 110
1100 C(1,00) = 1.2
1110 XNAME(1) = TVIN(IX,1)
1120 VNAME(1) = TVIN(IV,1)
1130 IF (IV2.NE.200) V2NAME(1) = TVIN(IV2,1)
1140 IF (IV2.EQ.200) V2NAME(1) = TVIN(IV2,1)
1150 IF (IV2.NE.200) V1TV(PROUT,1030) XNAME,IX,V1NAME,IV1,V2NAME,IV2
1160 FORMAT (1X,SELECTED VARIABLES =//10X,3(24X,10,13,10,5X))
1170 WRITE (PRINT,1040) (ISLCT(I),I=1,2),I=1,PRON)
1180 FORMAT (1X,SELECTED OBSERVATION Pairs =//1X,10(1X,15,10,15,1X))
1190 ICT1 = 0
1200 ICT2 = 0
1210 TOTAL1 = 0
1220 TOTAL2 = 0
1230 CALL GIVNM(0)
1240 FORMAT (610,6)
1250 IF (OPTION(6).NE.0) CALL MAXMIN(1,1,1,1,1,1,XMIN,X(1),XMINX(2),XMI
1X,X(1),XMAXX(4),XMINX(5),XMAXX(6))
1260 IF (OPTION(6).NE.0) CALL GIVNM(1)
1270 N1 = 160
1280 N2 = 1,PRON
1290 N3 = 160
1300 N4 = 1,PRON
1310 N5 = 160
1320 N6 = 1,PRON
1330 N7 = 160
1340 N8 = 1,PRON
1350 N9 = 160
1360 N10 = 1,PRON
1370 N11 = 160
1380 N12 = 1,PRON
1390 READ (ISTAPAC) TOLK,WT,CNSID,INDFT,X(1),I=1,10,(A(1),I=1,10)
1400 IF (TOLK.NE.0) GO TO 140
1410 IF (A(1X).NE.BLK).OR.(A(IV1).NE.BLK).AND.(A(IV2).NE.BLK).OR.(OP
1X,TVIN(2),CN,0).AND.(A(IV1).NE.BLK).OR.(A(IV2).NE.BLK))) GO TO 150
1420 IF (A(IV1).NE.BLK) GO TO 130
1430 ICT1 = ICT1+1
1440 TOTAL1 = TOTAL1+1
1450 X1PLOT(TOTAL1,X(IV1))
1460 X1PLOT(TOTAL1) = X(IV1)
1470 X1PLOT(TOTAL1) = X(IV1)
1480 X1PLOT(TOTAL1) = X(IV1)
1490 X1PLOT(TOTAL1) = X(IV1)
1500 X1PLOT(TOTAL1) = X(IV1)
1510 X1PLOT(TOTAL1) = X(IV1)
1520 X1PLOT(TOTAL1) = X(IV1)
1530 X1PLOT(TOTAL1) = X(IV1)
1540 X1PLOT(TOTAL1) = X(IV1)
1550 X1PLOT(TOTAL1) = X(IV1)
1560 X1PLOT(TOTAL1) = X(IV1)
1570 X1PLOT(TOTAL1) = X(IV1)
1580 X1PLOT(TOTAL1) = X(IV1)
1590 X1PLOT(TOTAL1) = X(IV1)
1600 X1PLOT(TOTAL1) = X(IV1)
1610 X1PLOT(TOTAL1) = X(IV1)
1620 X1PLOT(TOTAL1) = X(IV1)
1630 X1PLOT(TOTAL1) = X(IV1)
1640 X1PLOT(TOTAL1) = X(IV1)
1650 X1PLOT(TOTAL1) = X(IV1)
1660 X1PLOT(TOTAL1) = X(IV1)
1670 X1PLOT(TOTAL1) = X(IV1)
1680 X1PLOT(TOTAL1) = X(IV1)
1690 X1PLOT(TOTAL1) = X(IV1)
1700 X1PLOT(TOTAL1) = X(IV1)
1710 X1PLOT(TOTAL1) = X(IV1)
1720 X1PLOT(TOTAL1) = X(IV1)
1730 X1PLOT(TOTAL1) = X(IV1)
1740 X1PLOT(TOTAL1) = X(IV1)
1750 X1PLOT(TOTAL1) = X(IV1)
1760 X1PLOT(TOTAL1) = X(IV1)
1770 X1PLOT(TOTAL1) = X(IV1)
1780 X1PLOT(TOTAL1) = X(IV1)
1790 X1PLOT(TOTAL1) = X(IV1)
1800 X1PLOT(TOTAL1) = X(IV1)
1810 X1PLOT(TOTAL1) = X(IV1)
1820 X1PLOT(TOTAL1) = X(IV1)
1830 X1PLOT(TOTAL1) = X(IV1)
1840 X1PLOT(TOTAL1) = X(IV1)
1850 X1PLOT(TOTAL1) = X(IV1)
1860 X1PLOT(TOTAL1) = X(IV1)
1870 X1PLOT(TOTAL1) = X(IV1)
1880 X1PLOT(TOTAL1) = X(IV1)
1890 X1PLOT(TOTAL1) = X(IV1)
1900 X1PLOT(TOTAL1) = X(IV1)
1910 X1PLOT(TOTAL1) = X(IV1)
1920 X1PLOT(TOTAL1) = X(IV1)
1930 X1PLOT(TOTAL1) = X(IV1)
1940 X1PLOT(TOTAL1) = X(IV1)
1950 X1PLOT(TOTAL1) = X(IV1)
1960 X1PLOT(TOTAL1) = X(IV1)
1970 X1PLOT(TOTAL1) = X(IV1)
1980 X1PLOT(TOTAL1) = X(IV1)
1990 X1PLOT(TOTAL1) = X(IV1)
2000 X1PLOT(TOTAL1) = X(IV1)

```

UUUU

29

4


```

10 CALL PLOT1(2,CNF,IMP,0,0,0,0)
11 CALL PLOT1(2,CNF,CNF,CNF,101)
12 Y = 54000000
13 IF (1,GT,IMP) GO TO 14
14 ELDER = YMAX - FVISCAL
15 FUPPER = ELDER + VISCAL
16 IF (Y(11)-GT,UPPER OR, Y(11),LT, FLOWER) GO TO 14
17 A = (X(11)-XMIN)/XSCAL + 1.5
18 CALL PLOT1(2,SYMBOL(1),SYMBOL(2),SYMBOL(3),0)
19 I = I+1
20 GO TO 13
21 IF (J,GT,NSD2) GO TO 15
22 ELDER = YMAX - FVISCAL
23 FUPPER = ELDER + VISCAL
24 IF (Y(21)-GT,UPPER OR, Y(21),LT, FLOWER) GO TO 15
25 A = (X(21)-XMIN)/XSCAL + 1.5
26 CALL PLOT1(2,SYMBOL(2),SYMBOL(3),SYMBOL(3),0)
27 J = J+1
28 GO TO 14
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000

```

31

APPENDIX: Use of XYPLOT with the Card Entry Program

XYPLOT already assumes the data is located on a magnetic device in STATPAC format. STATPAC programs allow the user to perform transformations on the data, select observations, change data in error and other desired changes in the data. Therefore the serious user of this program should consult the STATPAC manual for the other programs in this series. It may be obtained from the U.S. Geological Survey, Computer Center Division, Department of the Interior.

The program which transfers the data from cards to tape is D0092. It is available as an object deck, a source deck, or on the system library.

The deck setup for using this program in conjunction with the XYPLOT program is shown on the next page. (This assumes the library is used to obtain a copy of D0092.)

PUNCHING INSTRUCTIONS

JOB	
BY	DATE

[illegible]

FIELD IDENTIFICATION

[illegible]

```
11/W00000AA TAB (1,1,1,1,1,1,0002,0020,0000,1,1,T,61),NAME
```

211 MSGLEVEL=1, CLASS=C

3//J08LIB 3D DSM=SYS).LOADLIB,DISP:(SHR,KEEP)

17 EXEC PGM=DD092

5//FT06F001 DD SYSOUT: A

6//FTII FOOL DD DSN=GTMP, UNIT=SYSDK, JISP. (PASS, DELETE).

```

// DCB=(RECFM=VB,LRECL=104,BLKSIZE=7180)

```

```
// SPACE=(TRK,(100,10),RLSE)
```

01/FT 05F001 DD *

	CARD	FOR	D092
Control			

DATA FOR D0092

12/21

13

10 // EXEC LINKFRT, REGION. GM=100K TIME.60:2

LINKED, SYSTEM DD *

OBJECT DECK

17/*

11//60.FT10FO01 DD DSN: 6TEMP, UNIT: SYSDK, DISP: (OLD, DELETE DELETE)

```
// DCB=(RECFM=VB, LRECL=104, BLKSIZE=7180)
```

01/60 SYSTEM DD *

IBM GENERAL PURPOSE CARD PUNCHING FORM

PUNCHING INSTRUCTIONS

JOB	
BY	DATE

WRITTEN AS:									
PUNCH AS:									

NOTES:

FIELD IDENTIFICATION

1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80
1 2 3 4 5 6 7 8 9 0	1 2 3 4 5 6 7 8 9 0	1 2 3 4 5 6 7 8 9 0	1 2 3 4 5 6 7 8 9 0	1 2 3 4 5 6 7 8 9 0	1 2 3 4 5 6 7 8 9 0	1 2 3 4 5 6 7 8 9 0	1 2 3 4 5 6 7 8 9 0

CONTROL CARDS FOR XYPLDT

- 1
- 2 / *
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11
- 12
- 13
- 14
- 15
- 16
- 17
- 18
- 19
- 20

APPENDIX: SAMPLE PROBLEM

Suppose one is given 50 observations with 6 variables, and one wants the X-variable to be input variable number 3, the first dependent variable to be input variable 2, and the second Y-variable to be input variable 5. Only observations 6 and 31-50 are to be used for the plot. The plot is to have 50 lines in the Y-direction, with the scales selected by the program. There are to be 50 points per plot; the variable names are also to be changed. The data is named DATAbINb.

The data is located on the tape 003516. The input deck and the results follow.

X-Y PLOTTING

TITLE
TEST OF PLOTTING PROGRAM

INPUT TO DRAINAGE	N 448	M 10	***** OPTIONS *****
			0 1 1 0 0 0 0 0 0


SELECTED VARIABLES -
PH (1)

TEMP (2)	AC TH (3)
------------	-------------


SELECTED OBSERVATION PAIRS -
1- 38

GRAPHICAL ANALYSIS.....TEST OF PLOTTING PROGRAM

..... = TEMP



GRAPHICAL ANALYSIS.....TEST OF PLOTTING PROGRAM



X-Y PLOTTING

TITLE
TEST OF PLOTTING PROGRAM

INPUT ID
DRAINAGE

N
448

M
10

***** OPTIONS *****
0 1 1 0 0 0 0 0 0

NUMBER OF VALID OBSERVATIONS FOR

PH

VERSUS

TEMP

-

31

NUMBER OF VALID OBSERVATIONS FOR

PH

VERSUS

AC TH

-

35